```
* Module: mod counter
* Author: Noah Hanks
* Class: ECEN 220, Section 3, Fall 2020 - ECEN 220, Section 1, Winter 2020
* Date: 28 Oct 2020
* Description: Creates a counter that goes up to mod 10.
***************************
`default nettype none
module mod counter #(MOD VALUE = 10, BIT NUMBER = 4)(
   input wire logic clk, reset, increment,
   output logic rolling over,
   output logic[BIT NUMBER - 1:0] count );
   always ff @(posedge clk) begin
       if(reset | ((count == MOD VALUE - 1) & increment))
           count <= {BIT NUMBER * {1'b0}} ;</pre>
       else if((count < MOD VALUE - 1) & increment)</pre>
           count <= count + 1;</pre>
       end
  assign rolling over = ((count == MOD VALUE - 1) & increment);
   endmodule
```

/*******************************

`timescale 1ns / 1ps